






0199




Position ID	Part number.	Replaces:	Description
0101	00772076		Control unit
0104	00752597		Cable harness
0105	00747781		Cover
0106	00629226		Clip
0107	00415861		Screw
0108	00752598		Socket




Position ID	Part number.	Replaces:	Description
0201	00369194		Foot
0202	00612608		Roller set
0203	00703200		Roller set
0204	00629222		Bushing
0205	00616010		Grommet
0206	00623285		Cap
0207	00629219		Bracket
0209	00752594		Housing
0210	00633456		Clip
0212	00752595	00750673	Water Filter
0213	00422356		Screw
0214	00422462		Screw
0215	00422505		Hinge
0216	00628684	00422357	Screw
0217	00416148		Lock-clamp
0218	00754875		Hinge
0220	00415923	00415861	Screw
0221	00415980		fastening ring
0222	00752596		Cover
0224	00601759		Sleeve
0225	00422453		Screw
0226	00713882		Decor plate
0228	00713883		Panel-base
0230	00422476		Bracket
0231	00628684	00422357	Screw
0232	00422478		Bracket
0233	00422473		Washer
0235	00422415		Screw
0236	00629223		Connection
0237	00416133		Switch
0238	00422514		Cover
0239	00422500		Bracket
0240	00241206		Cover
0241	00416150	00416096	Holder
0242	00628682		fastening ring
0244	00422479		Hinge
0245	00703756		Roller set


Position ID	Part number.	Replaces:	Description
0248	12004874		Bracket
0249	00487989		Hinge
0254	00422477		Bracket
0255	00416124	00422513	Switch-door
0256	00422499		Bracket




Position ID	Part number.	Replaces:	Description
0302	00610303	00422668	Screw
0303	00145718		Compressor
0304	00609736	00422668	Screw
0305	00752609		Control unit
0306	00422672		Spacer
0307	00643645		Cable harness
0309	00751857		Bracket
0310	00647970		Blower motor
0311	00647971		Fan blade
0312	00752239		Wire
0313	00752240		Cable harness
0314	00616046		Screw
0315	00754456		Tube
0316	00415923	00415861	Screw
0317	00643647		Cable harness
0318	00422309		Clamp
0319	00415982		Switch
0320	00415862	00612613	Screw
0321	00752611		Cable harness
0322	00754455		Tube
0323	11004108		Tube
0324	00145561		Condenser
0325	00650140		Sealing strip
0328	00422356		Screw
0329	00752610		Control unit
0330	00752608		Control unit
0331	00752612		Power module
0332	00751858		Bracket
0350	00422405		Valve
0351	00422406		Valve
0354	00422409		Valve
0355	00422410		Valve
0356	00422400		Valve
0301	00791272		Inverter
0308	00093110		Dryer






Position ID	Part number.	Replaces:	Description
0401	00415923	00415861	Screw
0402	00616047		Bracket
0403	00145465		Evaporator
0404	00647972		Heating element
0405	00422414		Clamp
0406	00145466		Seal
0408	00422683		Damper
0409	00703203		Pan
0410	11004109		Tube
0411	00752613		Tube
0412	00751861		Tube
0413	11004110		Tube
0414	00653172		Support
0415	00491867		Thermistor
0450	00665709		Fixing kit
0453	00650732		Repair-set










Position ID	Part number.	Replaces:	Description
0502	00629243		Clip
0503	00629240		Water inlet
0506	00629237		Door
0509	00752602		Motor
0510	00629242		LED-Light bar
0515	00415923	00415861	Screw
0520	00770182		Housing
0525	00790505	11021685	Display




Position ID	Part number.	Replaces:	Description
0601	00752213		Tube
0602	00422640		Bracket
0603	00752614		Cable harness
0604	00743569		Panel
0605	00422690		Seal
0606	00629251		Valve-magnet
0607	00422684		Clamp
0609	00471788		Mounting bracket
0610	00752088		Cover
0611	00436628	00645956	Ice maker
0612	00628692		Apron
0613	00487772		Scraper
0614	00751865		Ice maker
0615	00628693	00422363	Regulator
0616	00628986		Screw
0617	00415898		Retaining plate
0620	00628698		Screw
0621	00674312		Ice maker
0621	11011667		Ice maker
0623	00751867		Cable harness
0629	12004876		Tube
0630	00653666		Tube




Position ID	Part number.	Replaces:	Description
0701	00143733		Ice container
0719	00491903		Key
0720	00645951		Latch
0721	00422631		Spring
0722	00422496		Screw
0723	00422448		Screw
0724	00609751		Holder
0725	00422635		Seal
0726	00612611		Drive shaft
0727	00669801		Housing
0728	00145506		Motor
0729	00668502		Cover
0730	00609753		Sleeve
0733	00422639		Washer





Position ID	Part number.	Replaces:	Description
0801	00771984		Shelf
0802	00491869		Support
0803	00422468		Screw
0805	11004111		Wine accessory
0806	00436758		Egg rack
0818	00422570		Cap
0819	00491871		Handle
0825	00436761		Spacer
0828	00436782		Spacer
0829	00415861		Screw
0850	00436759		Slide
0851	00436780		Spacer
0853	00436781		Spacer




Position ID	Part number.	Replaces:	Description
0901	00713175		Shelf
0903	00713174		Shelf
0904	00713176		Basket




Position ID	Part number.	Replaces:	Description
1001	00248041		Door
1002	00612597		Handle-cap shaped
1004	00616052		Spacer
1005	00618718	00415889	Screw
1006	00609329		Door hinge
1009	00771982	00241191	Seal-door
1010	00713948	00712827	Door-outer
1011	00665465		Handle
1012	00612599		Nut
1015	00422348		Screw
1016	00422427		Spacer
1017	00478840		Spacer
1019	00665509		Spacer
1027	00143740		Shelf
1028	00612600		Stud
1029	00612598		Handle-cap shaped



Position ID	Part number.	Replaces:	Description
1101	00715863		Door-freezer compartment
1102	00612597		Handle-cap shaped
1103	00612600		Stud
1104	00422724		Spacer
1105	00609333		Door hinge
1106	00618718	00415889	Screw
1108	00616052		Spacer
1109	00612599		Nut
1110	00612598		Handle-cap shaped
1111	00771983	00241193	Seal-door
1112	00478840		Spacer
1113	00665465		Handle
1115	00713950	00712832	Door-outer
1116	00601447		Screw
1117	00422427		Spacer
1119	00436947		Spacer
1122	00436825		Shelf
1150	00772077		Trimplate
1151	00772078		Trimplate




Position ID	Part number.	Replaces:	Description
1201	00491861		Air duct
1203	00416043		Screw
1204	00415861		Screw
1206	00653701		Duct
1208	00491969		Ventilation duct
1208	12005195		Inverter
1209	11004162		Water tank
1212	00629225		Air duct
1213	00751871		Distributor
1214	00752807		Thermistor
1216	00628696		Screw
1217	00656808		Cover
1218	00415861		Screw
1219	00679403		Duct
1220	00679404		Cover
1221	00746977	11004106	Control unit





Position ID	Part number.	Replaces:	Description
1301	00628958		Motor
1303	00416121		Fan blade
1304	00436895		Sealing strip
1305	00415923	00415861	Screw
1307	00752598		Socket
1309	00770180		Shelf
1310	00422611		Clip
1311	00143711		Cover
1313	00415923	00415861	Screw
1314	00747787		Duct
1315	00653659	00422613	PC board-receiver/ir
1316	00422616		Lens
1317	00422624		Slide
1318	00770179		Cover
1320	00422625		Tube
1321	00415861		Screw
1322	00491901		Cover
1324	00369181		Support
1326	00616053		Screw
1327	00143730		Rail
1328	00143732		Sealing strip
1329	00628699		Screw
1330	00422626		Spring
1331	00752600		Cable harness
1332	00422630		Bracket
1334	00653660	00422613	PC board-receiver/ir
1336	00422627		Pin
1337	00422628		Cover
1338	00616054		Sensor
1339	00628960		Grommet
1340	00422614	00650732	Repair-set
1341	00628959		Bracket
1342	00650732		Repair-set
1343	00656808		Cover
1344	00422468		Screw
1347	00747786		Support
1348	00143731		Rail

Position ID	Part number.	Replaces:	Description
1350	00143730		Rail
1351	00422615		Bracket



Position ID	Part number.	Replaces:	Description
1401	00712814		Cover
1402	00713881		Cover
1403	00415923	00415861	Screw
1404	00471749		Panel
1405	00771978		Cover
1407	00647977		Cable harness
1408	00612614		Screw
1410	00422568		Grommet



Position ID	Part number.	Replaces:	Description
1501	00713765	00712576	Trimplate
1503	00422415		Screw
1504	00666013		Trimplate
1505	00415923	00415861	Screw
1506	00747789		Trimplate
1507	00713764	00770176	Trimplate
1509	00241177		Seal
1510	00628684	00422357	Screw
1550	00648875		Paint